


de Differenzdruck-Messumformer
 fr Transmetteurs de pression différentielle
 en Transducer for differential pressure
 it Convertitore di misura della pressione diff.
 es Transmisor de presión diferencial
 sv Mätvärdesomvandlare för differensstryck
 nl Verschilddruk-meetomvormer





de Montagevorschrift
 fr Instruction de montage
 en Fitting instructions
 it Istruzioni di montaggio
 es Instrucciones de montaje
 sv Montagevoorschrift
 nl Monteringsanvisning

EGP100F301
 EGP100F401
 EGP100F601



de Installationsanweisung für die Fachkraft/Monteur
 fr Notice d'installation pour le spécialiste/monteur
 en Guidelines for the technician/fitter
 it Informazioni per il personale specializzato di montaggio
 es Instrucciones para el especialista del ramo/montador
 sv Installationsinstruktion för installatör/montör
 nl Instalatie aanwijzing voor de vakman/monteur




i EGP100F301: $\Delta p = 0 \dots 150$ Pa
 EGP100F401: $\Delta p = 0 \dots 300$ Pa
 EGP100F601: $\Delta p = 0 \dots 1000$ Pa



3.1




3.2




B11330

3.3




4.1 zero



B11335


4.2

de Filter (τ)
 fr Filtre (τ)
 en Filter (τ)
 it Filtro (τ)
 es Filtro (τ)
 sv Filter (τ)
 nl Filter (τ)



B11336

5



B11337



de www.sauter-controls.com ➔ Produkte ➔ Material- und Umweltdeklaration
 fr www.sauter-controls.com ➔ Produits ➔ Déclaration matériaux et environnement
 en www.sauter-controls.com ➔ Products ➔ Materialdeclaration
 it www.sauter-controls.com ➔ Products ➔ Materialdeclaration
 es www.sauter-controls.com ➔ Products ➔ Materialdeclaration
 sv www.sauter-controls.com ➔ Products ➔ Materialdeclaration
 nl www.sauter-controls.com ➔ Products ➔ Materialdeclaration

de Dokument aufbewahren
 fr Ce document est à conserver
 en Retain this document
 it Conservare il documento
 es Guardar el documento
 sv Spara dokumentationen
 nl Document bewaren

© SAUTER HeadOffice
 Fr. Sauter AG
 Im Surinam 55
 CH-4058 Basel
 Tel. +41 61 - 695 55 55
 Fax +41 61 - 695 55 10
www.sauter-controls.com
info@sauter-controls.com