




MV 50517

0370880

Zubehör: Hubanzeige / Hilfsschalter / Potentiometer
Accessoire: Unité d'interrupteurs auxiliaires / rhéostatique
Optional extras: Auxiliary switch unit / potentiometer unit
Accessorio: Contatti ausiliari / potenziometro
Accesorio: Unidad conmutador auxiliar / potenciómetro
Tillbehör: Hjälpbrytarehet / potentiometerenhet
Toeberehen: Hulpcontacteenheid / potentiometerenheid







Montagevorschrift
Instructions de montage
Fitting instructions
Istruzioni di montaggio
Instrucciones de montaje
Monteringsanvisning
Montagevoorschrift




AVM / AVF

Installationsanweisung für die Elektrofachkraft
 Notice d'installation pour l'électricien
 Guidelines for the electrician
 Informazioni per l'installatore elettrico
 Instrucciones de instalación para el electricista
 Installationsinstruktion för behörig elektriker
 Instalatie aanwijzing voor de elektromonteur

Für den Einsatz in üblicher Umgebung
 Pour usage dans un environnement normal
 For use in normal environments
 Per impiego in ambiente usuale
 Para el uso en ambiente normal
 För användning i normal miljö
 Voor toepassing in normale omgeving










4 **0370881** →

Hilfsummschaltkontakt
 Contact auxiliaire inverseur
 Auxiliary change over contacts
 Contatti ausiliari
 Unidad conmutador auxiliar
 Hjälpbrytarehet
 Hulpcontacteenheid

A01360a

Type
1C
 EN60730

B07721b



5 **0370882**

Hilfskontakt/Potentiometer
 Auxiliaire inverseur/Rhéostatique
 Auxiliary change/Potentiometer
 Contatti ausiliari/Potentiometro
 Conmutador auxiliar/Potenciómetro
 Hjälpbrytar/Potentiometerenhet
 Hulpcontact/Potentiometereenheid

bei/siff 230V

Type **1C**
EN60730

A06226a

B07726b

5.1

0370882 **7** **B07719**

5.2

B07727a

5.3

B07728

5.4

B07729a


AVF 113 (S) F2

5.5



B07730a

5.6

B07731a


6 **0370883** 

Potentiometer
Rhéostatique
Potentiometer unit
Potentiometro
Potenciométrico
Potentiometerenhet
Potentiometereenheid

A01363 B07732b


6.1



B07719


0370883 → **7**

6.2



B07733a


6.3



B07734a


AVF 113 (S) F2

6.4




B07735a

7a **370881, 370882, 370883**



B09886

7b



B09887