


de Differenzdruck-Messumformer  
 fr Transmetteurs de pression différentielle  
 en Transducer for differential pressure  
 it Convertitore di misura della pressione diff.  
 es Transmisor de presión diferencial  
 sv Mätvärdesomvandlare för differenstryck  
 nl Verschilddruk-meetomvormer

de Montagevorschrift  
 fr Instruction de montage  
 en Fitting instructions  
 it Istruzioni di montaggio  
 es Instrucciones de montaje  
 sv Montagevoorschrift  
 nl Monteringsanvisning

**EGP100F101**  
**EGP100F201**


de Installationsanweisung für die Fachkraft/Monteur  
 fr Notice d'installation pour le spécialiste/monteur  
 en Guidelines for the technician/fitter  
 it Informazioni per il personale specializzato di montaggio  
 es Instrucciones para el especialista del ramo/montador  
 sv Installationsinstruktion för installatör/montör  
 nl Instalatie aanwijzing voor de vakman/monteur



**i** EGP100F101:  $\Delta p = \pm 75 \text{ Pa}$   
 EGP100F201:  $\Delta p = \pm 150 \text{ Pa}$




**1**




M10490

**2.1**




B11328

**2.2**




B11326

**2.3**




B11329


**3.1**




**3.2**



**3.3**




**4.1 zero**




## 4.2

de Filter ( $\tau$ )  
 fr Filtre ( $\tau$ )  
 en Filter ( $\tau$ )  
 it Filtro ( $\tau$ )

es Filtro ( $\tau$ )  
 sv Filter ( $\tau$ )  
 nl Filter ( $\tau$ )



## 5



|    |  |            |  |
|----|--|------------|--|
| de | <a href="http://www.sauter-controls.com">www.sauter-controls.com</a> | ⇒ Produkte | ⇒ Material und Umweltdeklaration         |
| fr | <a href="http://www.sauter-controls.com">www.sauter-controls.com</a> | ⇒ Produits | ⇒ Déclaration matériaux et environnement |
| en | <a href="http://www.sauter-controls.com">www.sauter-controls.com</a> | ⇒ Products | ⇒ Material declaration                   |
| it | <a href="http://www.sauter-controls.com">www.sauter-controls.com</a> | ⇒ Products | ⇒ Material declaration                   |
| es | <a href="http://www.sauter-controls.com">www.sauter-controls.com</a> | ⇒ Products | ⇒ Material declaration                   |
| sv | <a href="http://www.sauter-controls.com">www.sauter-controls.com</a> | ⇒ Products | ⇒ Material declaration                   |
| nl | <a href="http://www.sauter-controls.com">www.sauter-controls.com</a> | ⇒ Products | ⇒ Material declaration                   |

de Dokument aufbewahren  
 fr Ce document est à conserver  
 en Retain this document  
 it Conservare il documento  
 es Guardar el documento  
 sv Spara dokumentationen  
 nl Document bewaren

© SAUTER HeadOffice  
 Fr. Sauter AG  
 Im Surinam 55  
 CH-4016 Basel  
 Tel. +41 61 - 695 55 55  
 Fax +41 61 - 695 55 10  
[www.sauter-controls.com](http://www.sauter-controls.com)  
[info@sauter-controls.com](mailto:info@sauter-controls.com)